


## 4.3 Semiconductors

## 4.4 Electron effective mass

### Conductor (metal):



The electron is like a ball rolling on almost flat ground:




Electron can move easily

**Insulator:**

ENERGY gap- no ALLOWED levels




Electron is in a pit,



It can't move without a big boost.


**Semiconductor:**

Half way in between a conductor and an insulator.



Little gap to empty levels, shallow pit.






UST Spring 2010

PHYS 225 Applications of Modern Physics: from the atom to the diode


5



UST Spring 2010

PHYS 225 Applications of Modern Physics: from the atom to the diode


6

**Table 4.2** Effective mass  $m_e^*$  of electrons in some metals



Metal	Ag	Au	Bi	Cu	K	Li	Na	Ni	Pt	Zn
$\frac{m_e^*}{m_e}$	0.99	1.10	0.047	1.01	1.12	1.28	1.2	28	13	0.85

## Semiconductor:



Half way in between a conductor and an insulator.




Little gap to empty levels, shallow pit.



The electronic structure of Si






Semiconductors:


							VIIIA
		IIIA	IVA	VA	VIA	VIIA	He 4.003
IB	IIB	B 10.811	C 12.011	N 14.007	O 15.999	F 18.998	Ne 20.183
		Al 26.982	Si 28.086	P 30.974	S 32.064	Cl 35.453	Ar 39.948
		Cu 63.54	Zn 65.37	Ga 69.72	Ge 72.59	As 74.922	Se 78.96
		Ag 107.870	Cd 112.40	In 114.82	Sn 118.69	Sb 121.75	Te 127.60
		Au 196.967	Hg 200.59	Tl 204.37	Pb 207.19	Bi 208.980	Po (210)
						At (210)	Rn (222)

Material	Band gap [ev] (T = 0K)	Band gap [ev] (T = 300K)
Si	1.17	1.11
Ge	0.74	0.66
InSb	0.23	0.17
InAs	0.43	0.36
InP	1.42	1.27
GaP	2.32	2.25
GaAs	1.52	1.43
GaSb	0.81	0.68
CdSe	1.84	1.74
CdTe	1.61	1.44
ZnO	3.44	3.2
ZnS	3.91	3.6
C (diamond)		5.5

### Semiconductors.:




What are possible ways could get electron to higher empty level (out of pit), so could move to conduct electricity?






### Ways to get electrons up to where they can move:

1. light-- photoconductors (copying machines, laser printers)
2. heat
3. designer impurities- tinker slightly with energy levels.


### 1. Photoconductors:




Physics of copying machines and laser printers.




## 4.5 Density of states





Each state, or electron wavefunctions in the crystal, can be represented by a box at  $n_1, n_2$ .



All the possible combinations of positive  $n_1$ ,  $n_2$ , and  $n_3$  values satisfy

$$n_1^2 + n_2^2 + n_3^2 \leq n'^2$$